

These fender struts are required when a short rear end is installed and the frame is shortened.

Screw the fender struts to the provided holes with the shortened frame and the rear fender.

Tightening torque: 10 to 15Nm

We recommend using a medium-strength screw lock (e.g. LOCTITE 243, blue) for all screws.



Abb. 1 – Mounted Fender Struts



Abb. 2 – Fender Struts