

Safety instructions:

- Jack up the vehicle for assembly so that it is secured against falling over and the rear wheel is not in contact with the ground.
- We recommend using a medium-strength screw lock (e.g. Loctite 243, blue).

Mounting licence plate holder:

1. loosen the lower screw of the left shock absorber (mounting point on the swingarm).
2. use the supplied pan-head screw (ISO7380, M12x70) to reattach the side number plate holder to the shock absorber.
3. the new number plate light must be connected electrically in a professional manner.

