

Mounting headlamp mask "Bad Look

- 1. Hold the mask against the original headlamp and determine exactly where the mask rests so that you can then apply the adhesive dots.
- 2. use the supplied mounting glue and apply it as shown in fig. 1 (do not use too little glue)
- 3. then we recommend fixing the mask as shown in fig. 2 two! (the drying time of the adhesive is approx. 12 hours).





Abb. 1 & 2 – Application of mounting adhesive and temporary fastening!







Abb. 3 - Headlamp Mask "Bad Look"